


- E Eluttag
- TV TV-uttag
- S Strömbrytare
- S2 Trapphuskontakt
- Te Teleuttag
- K Kronkontakt
- L Spotlight



- ⓔ Eluttag
- ⓉⓋ TV-uttag
- Ⓢ Strömbrytare
- Ⓢ2 Trapphuskontakt
- Ⓣe Teleuttag
- Ⓚ Kronkontakt
- Ⓛ Spotlight

